

CONSTELLATION

CONSTELLATION CO-AXIAL SMALL SECONDS 35 MM Red gold on leather strap

Caliber 2202

123.58.35.20.55.002

- **©** Co-Axial escapement
- Automatic
- Chronometer
- Sapphire crystal
- Anti-reflective treatment on both sides
- Sapphire crystal case back
- ® Gold 750‰ (18K)
- ♥ Watch with diamond(s)
- Limited Edition
- 3-year International Warranty
- Water-Resistant to a relative pressure of 10 bar (100 metres/330 feet)




WATCH FUNCTIONS

The crown has 2 positions:

1. Normal position (wearing position): when the crown is positioned against the case, the crown ensures that the watch is water-resistant.


Occasional winding: if the watch has not been worn for 40 hours or more, wind it up with the crown in position 1.

2. Time setting: hours – minutes – seconds. Pull the crown out to position 2. The seconds hand will stop. Turn the crown forwards or backwards. Synchronise the seconds by pushing the crown back to position $\bf 1$ to coincide with a given time signal.



FOLDOVER CLASPS

Opening (fig. 1): to open the clasp, press the two pushers on either side of the OMEGA buckle and pull upwards.



Closing (fig. 2): put the watch on your wrist and close the clasp by pushing on it with your thumb until you hear a click. (fig. 2).




fig. 2

Adjusting the length (fig. 3): free the longer section from the two slideways (A) and from the catch (B). Adjust the bracelet in the required direction and reinsert in the catch and the two slideways. Try the watch for size and readjust if necessary.

