

DE VILLE

CHRONOSCOPE CO-AXIAL 4-COUNTERS CHRONOGRAPH 41 MM Steel on steel

Caliber 3890

422.10.41.52.06.001

- **®** Co-Axial escapement
- Automatic
- Chronometer
- Sapphire crystal
- Anti-reflective treatment on both sides
- 3-year International Warranty
- Water-Resistant to a relative pressure of 10 bar (100 metres/330 feet)



WATCH FUNCTIONS

The crown has 3 positions:

1. Normal position (wearing position): when the crown is positioned against the case, the crown ensures that the watch is water-resistant.

Occasional winding: if the watch has not been worn for 52 hours or more, wind it up with the crown in position 1.

2. Correcting the day: pull the crown out to position 2, turn the crown backwards, then push the crown back to position 1.

Note: in the quick mode, the date is changed in two steps. Check that the day disc plate is centred after the change has been made. Date-setting is not recommended between 10 pm and 2 am. During this time lapse and under certain conditions, a safety element can prevent these corrective functions from working.

3. Time setting: hours – minutes – seconds. Pull the crown out to position 3. The seconds hand will stop. Turn the crown forwards or backwards. Synchronise the seconds by pushing the crown back to position $\bf 1$ to coincide with a given time signal.

CHRONOGRAPH FUNCTIONS

- Pusher A: start stop, start stop, etc Timing to 1/8 of a second for up to 7 days.
- Pusher B: reset (after a stop).

Note: resetting/zeroing of the sub dials must only be carried out after the chronograph has stopped.

