







## DE VILLE

PRESTIGE QUARTZ 24.4 MM

Yellow gold on yellow gold

Caliber  
**1376**

**424.50.24.60.08.001**

-  Quartz
-  Sapphire crystal
-  Gold 750‰ (18K)
-  Water-Resistant to a relative pressure of 3 bar (30 metres/100 feet)




### WATCH FUNCTIONS

The crown has 2 positions:


**1. Normal position (wearing position):** when the crown is positioned against the case, the crown ensures that the watch is water-resistant.

**2. Time setting:** hours – minutes. Pull the crown out to position 2. Turn the crown forwards or backwards. Push the crown back to position 1.



### FOLDOVER CLASPS

Using the fine length adjuster (fig. 5)



### Using the diving extension (fig. 6)

*Note: to fold the diving extension away, it is important to proceed according to fig. 6.2 (with the diving extension perpendicular to the cover of the clasp).*

